


DURAHIRIB

For lowsloped roofing, institutional, warehouses and commercial



PRODUCT INFO SUBSTRATES PAINT COATING SYSTEM Hot-dip Metallic Coated Steel Oven baked Oil free Polyester topcoat over a corrosion-resistant Primer with Oil free Polyester backing coat - Hot-dip Zinc-Coated Steel - Hot-dip 55% Aluminum-Zinc Alloy Coated Steel PVDF, SMP, available upon request NOMINAL THICKNESS 0.50 mm to 0.80 mm PAINT COATING Topcoat: 12 - 15 microns THICKNESS Backing Coat: 4-8 microns **FEED WIDTH** 1220 mm AVAILABLE COLORS Red, Green, Brown, Beige, Blue, White EFFECTIVE COVERAGE 980 mm (+/- 10mm) Charcoal Gray, Teracotta Orange, Fire Red **RIB HEIGHT** 50 mm Other Colors available with terms and conditions applied LENGTH Customized length available with terms and conditions. Onsite rollforming for longer panels. * Bended Accessories Available (Stainless materials available upon request)

PRODUCT SPECIFICATIONS



HANDLING, STORAGE AND INSTALLATION GUIDELINES

- 1. Lift and bring down panels at its horizontal sides. Lifting may require two to three persons for longer panels.
- Panels should be stored in dry, shaded and good ventilated area. Avoid contact with wet lumber, soil or chemical contamination. Provide cover if not for immediate use.
- 3. When panels become wet during storage, separate without delay, remove surface moisture with clean cloth and stack so air can circulate and complete the drying process.
- 4. Panels should be piled over a pallet 10 cm from ground level and an inclination of 10° minimum.
- 5. Roof structures and frames must be properly anchored.
- 6. The spacing of the purlins must conform to the module distance required for the profile. Ensure that all purlins are in one planes and levelled.
- 7. Adjust purlins at the gutter eaves line by considering the thickness of the fascia board to be used.
- 8. Gutters must be installed first prior to the installation of roof panels.

Business Park, Brgy. San

Andres, Cainta, Rizal +63 905-514-7156

- always align the panels before anchoring to the purlins. For te proper alignment of panels, make sure that the first panel to be laid out properly aligned with the
 gutter line. Run a string from the edge of the first panel laid out across the last panel to be installed, align and fasten all the rest of the panels using the string line
 reference.
- 10. During installation, use rubber soled shoes and always step on or near the purlins to minimize indentations and prevent leakage due to it.
- 11. Always clean-off debris such as fasteners, rivets, metal filings, metal cuttings and other metallic pieces every each day of installation.
- 12. Minimize use of touch-up paint.

Rockwell Center, Makati City

(02)8870-0548, (02) 8870-0368

NORTH LUZON SOUTH LUZON NORTHWESTERN MINDANAO LA UNION ROLLFORMING PLANT SAN NICOLAS SALES OFFICE MAIN PLANT AND CAGAYAN DE ORO OZAMIS SALES OFFICE BATANGAS ROLLFORMING PLANT O Poro Pt., San Fernando City, O Brgy. 12, San Cayetano, San O HEAD OFFICE ROLLFORMING PLANT Rizal Ave., Lam-an, Nicolas, Ilocos Norte Brgy. Soro-Soro, Karsada Cor. Malasag Road Zone 9, Ozamis City La Union Chipeco Avenue Extension, Brgy. (072) 242-0331/32 (077) 770-3773 Real, Calamba City, Laguna Batangas City Cugman, Cagayan De Oro City (088) 521-5002 +63 923-829-0058 +63 922-366-1749 +63 922-411-4141 (02) 8520-8822 to 23 **(**088) 855-1563, (088) 521-4998 ☐ Globe +63 917-503-3965. (088) 855-1684 +63 917-777-0898 BENGUET SALES OFFICE PANGASINAN SALES OFFICE Smart +63 919-003-2303 +63 906-875-5883 Palmaville, Puguis, LaTrinidad, Brgy. Nalsian, Calasiao, QUEZON WAREHOUSE ZAMBOANGA Benguet Pangasinan BICOL (074) 665-8685 Purok Ilang Ilang II, Brgy. (075) 523-9799, (075) 517-3970 ROLLFORMING PLANT ROLLFORMING PLANT +63 906-568-5301 +63 921-984-4268 Silangan Mayao Lucena City O Princeton Warehouse San 0 LB Compound, Veterans Ave. L +63 923-839-8073 Sta. Maria, Zamboanga City Jose, Pili, Camarines Sur BANTAY SALES OFFICE VILLASIS SALES OFFICE +63 951-108-0313 (062) 992-7957/7959 Brgy., Puspus, Bantay, Ilocos Sur O Bray, Bacaa, Villasis, +63 997-955-4339 (077) 604-2994 Pangasinan **WESTERN VISAYAS** +63 923-286-0245 (075) 524-7233 SOUTH MINDANAO BACOLOD +63 968-852-8412 ROLLFORMING PLANT ROLLFORMING PLANT DAVAO BUTUAN Circumferential Road, Brgy. **CENTRAL LUZON** Lki. 3 Bldg., Lacson Ext. St., ROLLFORMING PLANT ROLLFORMING PLANT Brgy. Singcang-Airport, Tacas, Jaro, Iloilo City Bo. Ilang, Davao City O Butuan Premier PAMPANGA ROLLFORMING PLANT ISABELA SALES OFFICE Bacolod City (033) 323-4500 (082) 238-0592. Warehouse, Km. 3 Baan. McArthur Highway, Brgy. Baliti, City of Olma Bldg., Purok Nieto, (034) 474-2673 +63 942-951-2521 (082) 238-0593 Butuan City San Fernando, Pampanga 2000 Maharlika Highway, Batal, +63 950-750-9615 +63 922-655-6765 (085) 815-5692 (045) 455-2490 or (045) 455-5139 Santiago City, Isabela +63 925-731-2906. +63 906-712-8854 +63 917-169-0913 **CENTRAL & EASTERN VISAYAS** GENERAL SANTOS +63 977-841-4841 +63 917-829-1593 SALES OFFICE NUEVA ECIJA SALES OFFICE CEBU **TACLOBAN** Km 3 Bty Compound, National Piazza Veintidos Building, Brgy. San ROLLFORMING PLANT ROLLFORMING PLANT Highway, Brgy. Apopong, O Bray, 82, National Miguel Na Munti, Talavera, Nueva Ecija Pagutlan, Tayud, Consolacion. General Santos City Highway, Marasbasras +63 965-738-5230 Cebu (083) 552-6116 (032) 260-4429 Tacloban City NATIONAL CAPITAL REGION +63 963-124-5496 (032) 260-4432 (053) 832-4247 MAKATI OFFICE CAINTA ROLLFORMING +63 949-362-9271 +63 997-297-4085 3/F 39 Plaza Drive, PHINMA Plaza, O Warehouse 1B, Mercedes