



## **PRODUCT INFO** PAINT COATING SYSTEM **SUBSTRATES** Hot-dip Metallic Coated Steel Oven baked Oil free Polyester topcoat over a corro-- Hot-dip Zinc-Coated Steel sion-resistant Primer with Oil free Polyester backing coat PVDF, SMP, available upon request - Hot-dip 55% Aluminum-Zinc Alloy Coated Steel NOMINAL THICKNESS 0.30 mm to 0.60 mm PAINT COATING THICKNESS Topcoat: 12 - 15 microns Backing Coat: 4-8 microns **FEED WIDTH** 915 mm and 1220 mm AVAILABLE COLORS Red, Green, Brown, Beige, Blue, White EFFECTIVE COVERAGE Charcoal Gray, Teracotta Orange, Fire Red 780 mm and 1064 mm (+/- 5mm) **RIB HEIGHT** Other Colors available with terms and conditions applied LENGTH Customized length available with terms and conditions \*\* Inverted Minirib Profile Available





## HANDLING, STORAGE AND INSTALLATION GUIDELINES

- . Lift and bring down panels at its horizontal sides. Lifting may require two to three persons for longer panels.
- 2. Panels should be stored in dry, shaded and good ventilated area. Avoid contact with wet lumber, soil or chemical contamination. Provide cover if not for immediate use.
- When panels become wet during storage, separate without delay, remove surface moisture with clean cloth and stack so air can circulate and complete the drying process.
- 4. Panels should be piled over a pallet 10 cm from ground level and an inclination of 10° minimum.
- 5. Roof structures and frames must be properly anchored.
- 6. The spacing of the purlins must conform to the module distance required for the profile. Ensure that all purlins are in one planes and levelled.
- 7. Adjust purlins at the gutter eaves line by considering the thickness of the fascia board to be used.
- 8. Gutters must be installed first prior to the installation of roof panels.

Andres, Cainta, Rizal

+63 905-514-7156

- 9. always align the panels before anchoring to the purlins. For te proper alignment of panels, make sure that the first panel to be laid out properly aligned with the gutter line. Run a string from the edge of the first panel laid out across the last panel to be installed, align and fasten all the rest of the panels using the string line reference.
- 10. During installation, use rubber soled shoes and always step on or near the purlins to minimize indentations and prevent leakage due to it.
- 11. Always clean-off debris such as fasteners, rivets, metal filings, metal cuttings and other metallic pieces every each day of installation.
- 12. Minimize use of touch-up paint.

(02)8870-0548, (02) 8870-0368

## NORTH LUZON SOUTH LUZON NORTHWESTERN MINDANAO LA UNION ROLLFORMING PLANT SAN NICOLAS SALES OFFICE MAIN PLANT AND CAGAYAN DE ORO OZAMIS SALES OFFICE **BATANGAS** O Poro Pt., San Fernando City, Brgy. 12, San Cayetano, San O HEAD OFFICE ROLLFORMING PLANT ROLLFORMING PLANT Rizal Ave., Lam-an. Brgy. Soro-Soro, Karsada, La Union Nicolas, Ilocos Norte Chipeco Avenue Extension, Brgy. Cor. Malasag Road Zone 9 Ozamis City (072) 242-0331/32 (077) 770-3773 Real, Calamba City, Laguna Cugman, Cagayan De Oro City (088) 521-5002, +63 923-829-0058 +63 922-411-4141 (02) 8520-8822 to 23 +63 922-366-1749 (088) 855-1563 (088) 521-4998 +63 917-777-0898 Globe +63 917-503-3965 (088) 855-1684 BENGUET SALES OFFICE PANGASINAN SALES OFFICE Smart +63 919-003-2303 +63 906-875-5883 Palmaville, Puquis, LaTrinidad. O Brgy. Nalsian, Calasiao, QUEZON WAREHOUSE BICOL ZAMBOANGA Benguet Pangasinan (074) 665-8685 (075) 523-9799, (075) 517-3970 ROLLFORMING PLANT ROLLFORMING PLANT Purok Ilang Ilang II, Brgy. +63 906-568-5301 +63 921-984-4268 Silangan Mayao, Lucena City Princeton Warehouse, San O LB Compound, Veterans Ave. Jose, Pili, Camarines Sur +63 923-839-8073 Sta. Maria. Zamboanga City BANTAY SALES OFFICE VILLASIS SALES OFFICE +63 951-108-0313 (062) 992-7957/7959 Brgy., Puspus, Bantay, Ilocos Sur Brgy. Bacag, Villasis +63 997-955-4339 (077) 604-2994 WESTERN VISAYAS Pangasinan +63 923-286-0245 (075) 524-7233 SOUTH MINDANAO BACOLOD ILOILO +63 968-852-8412 ROLLFORMING PLANT ROLLFORMING PLANT DAVAO BUTUAN **CENTRAL LUZON** O Lki. 3 Bldg., Lacson Ext. St. Circumferential Road, Brgy ROLLFORMING PLANT ROLLFORMING PLANT Brgy. Singcang-Airport, Tacas, Jaro, Iloilo City Bo. Ilang, Davao City Butuan Premie PAMPANGA ROLLFORMING PLANT ISABELA SALES OFFICE Bacolod City (033) 323-4500 (082) 238-0592 Warehouse, Km. 3 Baan. McArthur Highway, Brgy. Baliti, City of Olma Bldg., Purok Nieto, (034) 474-2673 +63 942-951-2521 (082) 238-0593 Butuan City San Fernando, Pampanga 2000 Maharlika Highway Batal +63 922-655-6765 (085) 815-5692 (045) 455-2490 or (045) 455-5139 Santiago City, Isabela +63 925-731-2906 +63 917-169-0913 +63 906-712-8854 **CENTRAL & EASTERN VISAYAS GENERAL SANTOS** +63 977-841-4841 +63 917-829-1593 SALES OFFICE NUEVA ECIJA SALES OFFICE TACLOBAN CEBU Km 3 Bty Compound, National Piazza Veintidos Building, Brgy. San ROLLFORMING PLANT ROLLFORMING PLANT Brgy. 82, National Highway, Brgy. Apopong, Miguel Na Munti, Talavera, Nueva Ecija Pagutlan, Tayud, Consolacion General Santos City +63 965-738-5230 Cebu Highway, Marasbasras (083) 552-6116 (032) 260-4429. Tacloban City NATIONAL CAPITAL REGION +63 963-124-5496 (053) 832-4247 (032) 260-4432 MAKATI OFFICE CAINTA ROLLFORMING +63 949-362-9271 +63 997-297-4085 3/F 39 Plaza Drive, PHINMA Plaza, Warehouse 1B, Mercedes Rockwell Center, Makati City Business Park, Brgy. San